

MPower



MANUAL DE PARTES ROTOMARTILLO ZIC-DW-40B



**HERRAMIENTAS
ELÉCTRICAS**

YouTube



www.mpower.com.mx

MPOWER



ROTOMARTILLO/ZIC-DW-40B

HERRAMIENTAS
ELÉCTRICAS






ÍNDICE

ROTOMARTILLO ZIC-DW-40B

E-1	GENERAL ASSEMBLY	PAG 04
	ANEXO.....	PAG 11




GENERAL ASSEMBLY






GENERAL ASSEMBLY





GENERAL ASSEMBLY




GENERAL ASSEMBLY

SEC.	NO. PARTE	DESCRIPCIÓN	CANTIDAD
1	DW-40B-1	Front cover	1
2	DW-40B-2	Circlip	1
3	DW-40B-3	Washer	1
4	DW-40B-4	Slider	1
5	DW-40B-5	Spring	1
6	DW-40B-6	Screw M5X28	12
7	DW-40B-7	Spring washer $\phi 5$	12
8	DW-40B-8	Flat washer $\phi 5$	12
9	DW-40B-9	Cylinder housing	1
10	DW-40B-10	Grease Seal	1
11	DW-40B-11	Criclip	1
12	DW-40B-12	Big washer	1
13	DW-40B-13	Bearing 61808	2
14	DW-40B-14	Guard sleeve	1
15	DW-40B-15	Steel ball pole $\phi 8 \times 1$	2
16	DW-40B-16	Steel ball $\phi 7.94$	3
17	DW-40B-17	O-ring $\phi 28 \times \phi 2$	2
18	DW-40B-18	O-ring $\phi 19 \times \phi 2$	2
19	DW-40B-19	Second striker	1
20	DW-40B-20	Washer	1
21	DW-40B-21	Lock ring	1
22	DW-40B-22	Plastic pipe	1
23	DW-40B-23	Seal ring $\phi 68 \times \phi 59 \times 2.5$	1
24	DW-40B-24	Big washer $\phi 68 \times \phi 50 \times 2$	1
25	DW-40B-25	Steel ball $\phi 9$	3
26	DW-40B-26	Cylinder	1
27	DW-40B-27	Flat key 3x18	2
28	DW-40B-28	Big bevel gear	1
29	DW-40B-29	Striker	1
30	DW-40B-30	O-ring $\phi 28 \times \phi 3$	2
31	DW-40B-31	Piston pin	1
32	DW-40B-32	Piston	1


GENERAL ASSEMBLY

SEC.	NO. PARTE	DESCRIPCIÓN	CANTIDAD
33	DW-40B-33	Connecting rod	1
34	DW-40B-34	Needle bearing HK101612	1
35	DW-40B-35	Circlip for hole $\varnothing 56$	1
36	DW-40B-36	Oil bearing	1
37	DW-40B-37	Crank housing	1
38	DW-40B-38	Moving plate	1
39	DW-40B-39	Pin B4x40	1
40	DW-40B-40	Grease cover	1
41	DW-40B-41	O-ring $\varnothing 41 \times \varnothing 1.5$	1
42	DW-40B-42	Hexagon nut M12	1
43	DW-40B-43	Damping spring	1
44	DW-40B-44	Hexagon nut M12x40	1
45	DW-40B-45	Damping washer	1
46	DW-40B-46	Up damping cover	1
47	DW-40B-47	Seal ring	1
48	DW-40B-48	Small beaver gear	1
49	DW-40B-49	Flat pin 4x22	1
50	DW-40B-50	Bearing 16003	1
51	DW-40B-51	Bearing HK152012	1
52	DW-40B-52	Circlip $\varnothing 58$	1
53	DW-40B-53	Flower hole gear	1
54	DW-40B-54	Second gear	1
55	DW-40B-55	Washer	1
56	DW-40B-56	Circlip $\varnothing 15$	1
57	DW-40B-57	Clutch	1
58	DW-40B-58	Conical spring	1
59	DW-40B-59	Small washer	1
60	DW-40B-60	Bearing 608	2
61	DW-40B-61	Clutch spring	10
62	DW-40B-62	Steel ball $\varnothing 5.5$	10
63	DW-40B-63	Spring washer $\varnothing 4$	2
64	DW-40B-64	Hexagon nut M4X13	2


GENERAL ASSEMBLY


SEC.	NO. PARTE	DESCRIPCIÓN	CANTIDAD
65	DW-40B-65	Crank shaft	1
66	DW-40B-66	Flat pin 4x16	1
67	DW-40B-67	Bearing 6003	1
68	DW-40B-68	Circlip $\varphi 17$	1
69	DW-40B-69	Bearing cover	1
70	DW-40B-70	Small gear	1
71	DW-40B-71	First gear	1
72	DW-40B-72	Needle bearing HK101610	1
73	DW-40B-73	Gear housing	1
74	DW-40B-74	O-ring $\varphi 11 \times \varphi 1.5$	1
75	DW-40B-75	Knob handle	1
76	DW-40B-76	Circlip $\varphi 15$	1
77	DW-40B-77	Knob spring	1
78	DW-40B-78	Side switch	1
79	DW-40B-79	Small washer $\varphi 3$	1
80	DW-40B-80	Spring washer $\varphi 3$	1
81	DW-40B-81	Cross nut M3X12	1
82	DW-40B-82	Locking block	1
83	DW-40B-83	Bearing 6001	1
84	DW-40B-84	Rotor	1
85	DW-40B-85	Air guider	1
86	DW-40B-86	Self tapping screw ST4.8X60	2
87	DW-40B-87	Stator	1
88	DW-40B-88	Right handle	1
89	DW-40B-89	Self tapping screw ST4.2X19	9
90	DW-40B-90	Hexagon nut M6	1
91	DW-40B-91	Neon lamp cover	1
92	DW-40B-92	Trigger switch	1
93	DW-40B-93	Motor plastic housing	1
94	DW-40B-94	Damping block	1
95	DW-40B-95	Capacitor	1
96	DW-40B-96	Wiring loom	1


GENERAL ASSEMBLY

SEC.	NO. PARTE	DESCRIPCIÓN	CANTIDAD
97	DW-40B-97	Inductor	2
98	DW-40B-98	Self tapping screw ST4X12	4
99	DW-40B-99	Carbon brush set	2
100	DW-40B-100	Brush holding set	2
101	DW-40B-101	Connecting terminal	1
102	DW-40B-102	Down damping cover	1
103	DW-40B-103	Domed cap nut M6	1
104	DW-40B-104	Left handle	1
105	DW-40B-105	Cable sheath	1
106	DW-40B-106	Cable pressing plate	1
107	DW-40B-107	Self tapping screw ST4X16	2
108	DW-40B-108	Cable	1
109	DW-40B-109	Neon lamp	1
110	DW-40B-110	Bottom cover	1
111	DW-40B-111	Collar	1
112	DW-40B-112	Clamp holder	1
113	DW-40B-113	Side handle	1
114	DW-40B-114	Locking block	1
115	DW-40B-115	Stop rod	1
116	DW-40B-116	Square head screw M8X45	1
117	DW-40B-117	Outter cover	1
118	DW-40B-118	Inner cover	1
57-1	DW-40B-57-1	Screw M4X12	2
57-2	DW-40B-57-2	Stopping Plate	1
57-3	DW-40B-57-3	Stopping Pin	2
57-4	DW-40B-57-4	Reset Spring 6.5X0.7X8	2



ANEXO



MPOWER

MANUAL DE PARTES

**ROTOMARTILLO
ZIC-DW-40B**



LADA SIN COSTO
01.800.506.82.86

SÍGUENOS EN:

You Tube



www.mpower.com.mx

**Km 126.5 Carretera Federal México-Puebla, Momoxpan, Cholula, Puebla.
MÉXICO. CP 72760**